

Fall 2009 Trailer Service Specials

Primo Trailer Sales has the plan to get your trailer in top shape!

Single Axle Twelve Point Inspection

- Pack Wheel Bearings
- Inspect Trailer Frame
- Inspect Springs and Shackles or Torsion Axle
- Inspect Coupler
- Inspect Breakaway Switch (if applicable)
- Inspect Brakes and Magnets (if applicable)
- Inspect Tires for Unusual Wear
- Set Tire Pressure Including Spare
- Check Operation of all lights and directional signals
- Visual Inspection of Exterior
- Remove all Wheels (2)

All the above for only \$149.99. (PLUS PARTS)

Tandem Axle Fourteen Point Inspection

- Pack Wheel Bearings
- Inspect Trailer Frame
- Inspect Springs and Shackles or Torsion Axle
- Inspect Coupler
- Inspect Breakaway Switch (if applicable)
- Inspect Brakes and Magnets
- Inspect Tires for Unusual Wear
- Set Tire Pressure Including Spare
- Check Operation of all lights and directional signals
- Visual Inspection of Exterior
- Remove all Wheels (4)

All the above for only \$239.99. (PLUS PARTS)

Bearing Service

- Single Axle Bearing Service \$119.99 (PLUS PARTS)
- Tandem Axle Bearing Service \$209.99 (PLUS PARTS)

Trailer Undercoating

\$149.99 (PLUS PARTS)

w/non-drip rubberized undercoating, includes cleaning frame

Don't wait until spring to have your unit serviced or repaired because time at that time of the year is at a premium. We can take care of these repairs & more:

- Tires
- Brake service

Storage Solutions – RVs, Boats, Cars

Storage – Outdoor From \$55/mo. Lots of room in the yard

Storage – Indoor Up to 20' \$110/mo., Over 20' - \$110+\$5/linear foot/mo.

Storage – Auto Call for special winter storage rates for cars

Call our service department today.



(613) 596-9696
Toll Free (800) 558-5178
995 Moodie Dr. S., Nepean
(Ottawa), ON. K2R 1H4

Recommended Inspection Schedule from Dexter Axle for your Trailer Brakes, Suspension and Axles

Item	Function Required	Weekly	3 Months or 3000 Miles	6 Months or 6000 Miles	12 Months or 12000 Miles
Brakes	Test that they are operational	<i>At every use.</i>			
Brake Adjustment	Adjust to proper operating clearance		X		
Brake Magnets	Inspect for wear and current draw			X	
Brake Linings	Inspect for wear or contamination				X
Brake Controller	Check for correct amperage and modulation			X	
Trailer Brake Wiring	Inspect wiring for bare spots, fray, etc.				X
Breakaway System	Check battery charge and switch operation	<i>At every use.</i>			
Hub/Drum	Inspect for abnormal wear or scoring				X
Wheel Bearings & Cups	Inspect for corrosion or wear. Clean & repack.				X
Seals	Inspect for leakage. Replace if removed.				X
Springs	Inspect for wear, loss of arch.				X
Suspension Parts	Inspect for bending, loose fasteners, wear.			X	
Hangers	Inspect welds.				X
Wheel Nuts & Bolts	Tighten to specified torque values.		X		
Wheels	Inspect for cracks, dents or distortion.			X	
Tire Inflation Pressure	Inflate tires to mfg's specifications.	X			
Tire Condition	Inspect for cuts, wear, bulging etc.		X		