

Spring RV Service

Primo Trailer Sales has the plan to get your RV in top shape! Whether you own a Travel Trailer or 5th Wheel our factory trained technicians will get your RV ready for the road . . . and all the good times ahead!

Silver Service – Basic Spring Servicing

- Visual Inspection of Brake System
- Repack Wheel Bearings (4)
- Inspect Springs and Shackles
- Inspect Tires for Unusual Wear
- Set Tire Pressure Including Spare

All of the above for **ONLY \$209.99**. (PLUS PARTS)

To ensure you have no leaks add **Seal-Tech Leak Test** for **\$100.00**

Gold Service - 32 Point Inspection (Recommended)

- Inspect Trailer Frame
- Inspect Springs and Shackles
- Inspect Coupler
- Inspect Breakaway Switch
- Remove all Wheels (4)
- Inspect Brakes and Magnets
- Pack Wheel Bearings
- Check all Batteries
- Clean Cables and Add Water
- Inspect Tires for Unusual Wear
- Set Tire Pressure Including Spare
- Check Operation of all lights and directional signals
- Visual Inspection of Brake System
- Propane System Leak Test
- Water Pressure Test
- Dump Valve Inspection
- Clean Roof A/C Filters
- Check 110v System
- Check Water Heater
- Check Stove and Oven
- Check all Faucets and Drains
- Lubricate all Locks
- Inspect Fire Extinguisher
- Visual Inspection of Exterior
- Check Roof Seal
- Clean Burner on Fridge
- Inspect Electrode on Fridge
- Clean Burner Tube on Water Heater
- Adjust Airflow on Water Heater

All the above for **ONLY \$499.99**. (PLUS PARTS) (Reg. \$599.99 PLUS PARTS)

Inspection also includes a Free Exterior Wash (\$69.95 value).

Platinum Service - All of service provided in the **Platinum Package** plus the **Seal-Tech Test** for **\$599.99**



(613) 596-9696
Toll Free (800) 558-5178
995 Moodie Dr. S., Nepean
(Ottawa), ON. K2R 1H4

Recommended Inspection Schedule from Dexter Axle for your Trailer Brakes, Suspension and Axles

Item	Function Required	Weekly	3 Months or 3000 Miles	6 Months or 6000 Miles	12 Months or 12000 Miles
Brakes	Test that they are operational	<i>At every use.</i>			
Brake Adjustment	Adjust to proper operating clearance		X		
Brake Magnets	Inspect for wear and current draw			X	
Brake Linings	Inspect for wear or contamination				X
Brake Controller	Check for correct amperage and modulation			X	
Trailer Brake Wiring	Inspect wiring for bare spots, fray, etc.				X
Breakaway System	Check battery charge and switch operation	<i>At every use.</i>			
Hub/Drum	Inspect for abnormal wear or scoring				X
Wheel Bearings & Cups	Inspect for corrosion or wear. Clean & repack.				X
Seals	Inspect for leakage. Replace if removed.				X
Springs	Inspect for wear, loss of arch.				X
Suspension Parts	Inspect for bending, loose fasteners, wear.			X	
Hangers	Inspect welds.				X
Wheel Nuts & Bolts	Tighten to specified torque values.		X		
Wheels	Inspect for cracks, dents or distortion.			X	
Tire Inflation Pressure	Inflate tires to mfg's specifications.	X			
Tire Condition	Inspect for cuts, wear, bulging etc.		X		